

# Technical Tip:

## *WET APPLYING BRITELINE CUT TRANSLUCENT*

**I.** When using application fluids to detackify a graphic while installing, be sure all liquid wetting agent is squeegeed out from between the substrate and the vinyl. Excess liquid causes tenting or bubbling when the application tape is removed. Also, allow enough drying time before removing the application tape. Removal of the tape too soon could cause tiny air bubbles to form in the graphic.

**II.** For application of reverse cut, second surface signage try to avoid wetting agents if possible. When squeegee work is done after a wet application one may not be able to tell if good pressure has been applied uniformly since all the surfaces will appear glossy and look as if they have contacted the substrate. In fact, the graphics may just be laying on a film of water.

**III.** Approved application fluids are: RapidTac, Splash, Gap Quick Stick, and Autotech DGS

**IV. Please note:** There are other fluids advertised to increase adhesion to difficult surfaces. Briteline has yet to review these and any found in the market should be tested prior to use.

